



3-WHEEL SCOOTER PRODUCT MANUAL

Before Operating Your i-Glide Scooter,
Please Read The Enclosed Operating Instructions Completely

ENGLISH | SPANISH | GERMAN | FRENCH

Hello Glider,

You have made a great choice with your new i-Glide Scooter. We know your new i-Glide Scooter will bring you many moments of fun, joy, activity and adventure. Rest assure that you have purchased a high-quality, high- fun, well-loved product with an after-sales service program for any questions.

We've got you covered.

We don't need to convince you of all the fun you are going to have on your i-Glide scooter, however, to ensure your safety please read these instructions carefully. Remember to put these instructions in a safe place so you can refer to them if need be in the future. Now, it's adventure time, let's have some fun with your new i-Glide Scooter!

Enjoy your daily glides!

Your i-Glide Team

**Bringing outdoor scooter
adventures to communities
around the world**



Always Wear Protective Gear When Riding.
Adult Supervision For Assembly And Use.





Important Instructions and Warnings

IMPORTANT: Before allowing your child to use the i-Glide Scooter, please read these operating instructions carefully. Please make sure the handlebars are fully engaged and that all screws are tightened. Check all wheels have been correctly secured and tightened and that they show no signs of wear.

IMPORTANT: Undoing the axle screws several times will reduce the effect of the screw securing the product. This means that the screws may come loose with scooter usage. Please regularly check the screws and use the scooter after tightening all axle screws, front and back on your i-glide scooter.

WARNING: Adult required. This product contains small parts while unassembled.

WARNING: The i-Glide scooter needs to be used with caution, scooter skills are required to avoid falls or collisions causing injury to the user or third parties.

WARNING: The wearing of helmets and protective equipment for elbows, knees, wrists and palms with shoes that have flat rubber soles is recommended.

WARNING: Close quick-action lock securely and ensure that it is correctly positioned.

WARNING: Do not ride down slopes.

WARNING: Child must be supervised at all time s.

WARNING: Brake can become hot.

WARNING: Maximum permissible weight is 50kgs.

Operating Safety Instructions

- Allow your child to practice first to gain control of the i-Glide scooter. We recommend practice riding in a traffic-free car park or on open asphalt play areas.
- Ensure that your child always wears a helmet, wrist, elbow and knee pads. Shoes with rubber soles are recommended.
- Load capacity is up to 50kg body weight for the i-Glide scooter.
- Not to be used in traffic.
- Ensure that your child does not travel at speeds exceeding 5km/h.
- Ensure your child does not attempt any experiments or risky manoeuvres with the scooter. Riding style should always be adjusted to the personal skill of the rider.
- Ensure that your child does not ride on roads, paths or other places where motor vehicle traffic resides.
- Ensure that you or your child do not make any modifications or alterations to the i-Glide scooter which would put the safety of your child or yourself at risk. If you do, the guarantee is forfeited, none and void.
- Ensure that your child does not ride the i-Glide scooter in the dark or at night unsupervised.
- Only one child may ride on the scooter at any one time.
- Ensure that your child does not ride down any steep hills. The brake is not designed to decelerate from high downhill speeds. Always look ahead while riding the i-Glide scooter so that you can quickly come to a stop at any time. The brake can get hot with prolonged use. Avoid contact with skin.
- The brake pad becomes hot when it is used. Make sure that your child does not keep the brake on for a long period of time. Explain to your child that direct skin contact may cause burns.
- The scooter must not be used on wet, oil, sandy, icy rough or uneven surfaces. Never use the scooter in wet conditions.
- Kerbstones and cobblestone pavements affect your balance and are best not to ride your i-Glide scooter on.
- Watch out for longitudinal and transverse grooves in the asphalt! The narrow wheels may get stuck in tram rails and manhole covers resulting in wheel lock up.
- Some metal parts may corrode after a certain time, especially when used near the sea, left outdoors or in wet weather too often.

- The scooter may not be used on public roads. When riding on pedestrian walking areas, keep to the correct side according to the rules of the road as much as possible. Watch out for pedestrians, wheelchair users, cyclists, rollerblade riders and animals. Always observe traffic rules and regulations.
- Scooter (model no: 198) for 6+ year | Scooter (model no: 199) for 2+ year
- Always take care when handling your i-Glide scooter not to risk injuring your fingers.
- Explain to your child the risk of using the scooter. Supervise your child while they are using the i-Glide scooter.

HAVE FUN WITH YOUR NEW i-GLIDE SCOOTER!

Play Instructions

Hold on to the ends of the handlebar (T-Bar) with your hands. You can steer the scooter deck through the slightest of weight displacements. To get under way, stand with one leg (the foot approx. at 45° angle to the direction of travel) on the i-Glide scooter deck and push yourself off using the other leg. If you stand with your right leg on the i-Glide scooter deck, you can use the left leg to accelerate. If you stand with your left leg on the i-Glide scooter deck, you can use your right leg to accelerate. After gaining momentum stand with your legs apart on the i-Glide scooter deck, so that both feet are approx. at 45° angle to the direction of travel.


Enjoy your scooter!

WARNING: Do not attempt or do stunts, tricks or rider/roll backwards on your scooter. It is not made to withstand misuse, such as jumping, curb grinding or any other type of stunts. Racing, stunt riding, or other manoeuvres, such as trying to ride backwards, also enhance risk for loss of control, or may cause uncontrolled rider actions or reactions. Aggressively riding reduces your ability to manoeuvre and control. Take necessary precautions and practice in safe areas.

Brake

The brake is a friction brake and only designed for reduction of speed on flat surfaces – avoid going downhill at rapid speeds. Brake at low speed by gently pushing your foot, resting far back on the i-Glide scooter deck, against the back- wheel plate. You need to push harder if you are travelling faster, however, be careful: if you push the brake too hard and slow down too abruptly, you risk falling. It is best to practise braking at walking speed.


Attention: The brake and protection plate can get very hot. Do not touch after braking, this could result in burns to fingers and skin.



OPTIONAL SEAT SOLD SEPARATELY

Scooter Assembly

WARNING: Keep the kids in a safe distance while assembling the scooter to avoid accidental injuries



Red Push Button A, Handlebar B, Fixing Sleeve C, as shown in Figure A.



Scooter Hole D, as shown in Figure B.



Press Red Push Button A, Insert the Handlebar B with the flat side backwards in Scooter Hole D, as shown in Figure C. Wait for the 'click' sound to ensure Handlebar B is securely locked into scooter body.



Pull the fixing sleeve downward to strengthen stability of the Handlebar B and scooter body as shown in Figure D.



Adjustable T-Bar handlebar with available heights to accompany child's development as shown in Figure E.



Finish the scooter assembly and height adjustable, as shown in Figure F.

Scooter Disassembly

WARNING: Keep the kids in a safe distance while disassembling the scooter to avoid accidental injuries



Scooter, as shown in Figure A.



Pull the fixing sleeve upward, as shown in Figure B and Figure C



Press Red Push Switch with one hand and using the other hand to pull handlebar to separate the handlebar and scooter body, as shown in Figure D and Figure E.



Finish the scooter dis-assembly as shown in Figure F.

Scooter Seat Assembly (SOLD SEPARATELY)


WARNING: Keep the kids in a safe distance while disassembling the scooter to avoid accidental injuries



Scooter, as shown in **Figure A**.




Put seat housing onto steering rod.



Insert the front covering into seat housing.



Fix and tighten with seat securing bolt



Finish scooter shown in **Figure E**.

Scooter Seat Disassembly (SOLD SEPARATELY)

WARNING: Keep the kids in a safe distance while disassembling the scooter to avoid accidental injuries




Scooter, as shown in **Figure A**.




Unscrew front seat securing bolt..



Remove front cover of seat.



Detach the main seat.



Finished scooter shown in **Figure E**.

Handlebar Height Adjustments

WARNING: Tighten the collar clamp to secure the handlebar (T-Bar) after adjustment.



Loosen the lever of the collar clamp, as shown in **Figure A**.



Adjust the T-bar according to child's height. Tighten the collar clamp to secure T-Bar after adjustments, as shown in **Figure B**.

Maintenance Instructions

Changing a Wheel

The wheels wear down with time and can be damaged if overly used on rough surfaces. The back wheel on which the brake is applied is particularly affected after several hours of braking. In the interest of safety, they should be checked regularly and changed if necessary.




Left Wheel: Turn the allen key anti-clockwise to loosen the screw.



Right Wheel: Turn the allen key clockwise to loosen the screw.

Changing the Deck

1. Loosen the 6 screws **A** as shown on the picture.
2. Remove deck and tighten the screw **A**.
3. Check for tight fit after you have travelled about 5km with the new board.



Remove or change the collar clamp

1. Loosen the 2 screws **A** and **B** as shown on the diagram picture.
2. Pull the collar clamp upwards and remove it.
3. Tighten the screws **A** and **B**.



More Safety Tips

The i-Glide Scooter is a fun product which is safe when used carefully and correctly. However, as with any sporting products, a small risk cannot be excluded, and we recommend that you protect your hands, joints, elbows and knees for bumps and grazes. A helmet will also contribute to your safety. To ensure you do not slip it is best if you wear shoes with rough sole. You should always adjust your speed according to your ability and the conditions, when in doubt, dismount if there is a risk of unseen traffic or hazards.

Warranty

MAINTENANCE

Regularly check that all screws are firmly secured and inspect the condition of your i-Glide Scooter wheels, tighten and or change wheels if necessary. Clean the i-Glide Scooter after each use with a damp soft cloth. By inspecting your scooter regularly, this will ensure you get the most out of your i-Glide scooter, extending the life of the scooter and possible unnecessary injuries.

LIMITED WARRANTY

The i-Glide scooter is covered by a 24 month warranty for material and manufacturing defects. Within the warranty period, it is at the discretion of the retailer and or distributor to decide whether products under warranty are repaired or replaced. The warranty does not cover any damage caused by misuse, such as incorrect mounting, negligent operation, impact against kerbs, etc, or normal wear and tear.

WARRANTY

A warranty claim only becomes effective upon presentation of proof of purchase! For this reason, it is important to safeguard your receipt. In the case of warranty claim, your retailer or distributor, will decide whether the i-Glide scooter will be repaired or replaced by a new model.

No person, seller, distributor shall be allowed to modify or to supplement the terms and conditions of this limited warranty.





 **i-GLiDE**



Bringing
outdoor scooter
adventures
to communities around the world